

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L

SONY STANDARD





A1  
' 18.08

SONY

Area		JAPAN	NORTH AMERICA	EUROPE	GENERAL AREA	CHINA
Model Name		FW-75BZ30J	FW-75BZ30J	FW-75BZ30J	FW-75BZ30J	FW-75BU30J




WITH STAND

STANDARD POSITION






WITH STAND


NARROW POSITION  
FW-75BZ30J  
(EUROPE Model only)



WITHOUT STAND





For .NORTH AMERICA, CHINA, GENERAL AREA



For .JAPAN

For .EUROPE



SU-WL 850

SU-WL 855 WITH LATERAL SHAFT BRACKET

