

## BZモデルとの比較

### EZ20Lで対応するプロ設定項目

プロ設定		BZ モデル	EZ20L	
プロ設定 (Android TV OS 10)	アクション	プロモードを開始	✓	-
		通常モードに移行	✓	-
		プロ設定リセット	✓	✓
		プロ設定内容	✓	-
		プロ設定のコピー	✓	-
		起動サービス	✓	-
		APKのインストール	✓	✓
	機能設定	AC起動設定	✓	-
		PC画面の最適化表示	✓	✓
		信号検出による電源制御と入力切換	✓	✓
		ホームボタン設定	✓	-
		NTPサーバー	✓	-
		アカウントの有効期間	✓	-
		プロモードの保護	✓	✓ (Lock settings)
		電源オフ中のUSB充電	✓	-
		画質・音質設定の復元	✓	-
		ストア機能	✓	-
		アプリによる電源制御	✓	-
		Wi-Fiアクセスポイント	✓	-
		管理者パスワード	✓	-
		USBドライブ自動実行	✓	-
		HTML5プラットフォーム	✓	-
	テレビ起動時の設定	初期入力	✓	✓
		初期音量と最大音量	✓	-
		電源スケジューリング	✓	✓
		定期的な再起動	✓	✓
	機能制限	本体キー・リモコン	✓	✓
		タッチパネルによる電源オン	✓	-
		ワイド切換	✓	-
		スクリーンミラーリング	✓	-
		外部入力	✓	✓
		アプリ	✓	-
		入力切換	✓	-
	クイック設定	✓	-	

## EZ20Lで対応する そのほかの機能

そのほかの機能		BZ model	EZ20L	
Control	IP control	WebAPI	✓	
		RCC-IP	✓	
		SSIP	✓	✓ (Simple IP control)
		Serial Control	✓	✓ (RS232C control)
		Crestron connected	✓	—
		Control4®	✓	—
Apps	Built-in	BRAVIA signage free	✓	
		AirPlay	✓	✓
		Chromecast	✓	✓

## EZ20Lで対応するコントロールコマンド

### 簡易 IP コントロールコマンド

Command Name	BZ model	EZ20L
setIrcCode	✓	✓
setPowerStatus	✓	✓
getPowerStatus	✓	✓
togglePowerStatus	✓	✓
setAudioVolume	✓	✓
getAudioVolume	✓	✓
setInput	✓	✓
getInput	✓	✓
setPictureMute	✓	✓
getPictureMute	✓	✓
togglePictureMute	✓	✓
getBroadcastAddress	✓	✓
getMacAddress	✓	✓
setSceneSetting	✓	✓
getSceneSetting	✓	✓
firePowerChange	✓	✓
fireInputChange	✓	✓
fireVolumeChange	✓	✓
fireMuteChange	✓	✓

## IR コマンド

IR Commands	BZ model	EZ20L
Display	✓	✓
Home	✓	✓
Options	✓	✓
Return	✓	✓
Up	✓	✓
Down	✓	✓
Right	✓	✓
Left	✓	✓
Confirm	✓	✓
Red	✓	✓
Green	✓	✓
Yellow	✓	✓
Blue	✓	✓
Num 0-9	✓	✓
Volume Up	✓	✓
Volume Down	✓	✓
Mute	✓	✓
Channel Up	✓	—
Channel Down	✓	—
Subtitle	✓	—
DOT	✓	✓
Picture Off	✓	✓
Wide	✓	—
Jump	✓	—
Sync Menu	✓	—
Forward	✓	✓
Play	✓	✓
Rewind	✓	✓
Prev	✓	✓
Stop	✓	✓
Next	✓	✓
Pause	✓	✓
Flash Plus	✓	✓
Flash Minus	✓	✓
TV Power	✓	✓
Audio	✓	—
Input	✓	✓
Sleep	✓	✓
Sleep Timer	✓	✓
Video 2	✓	✓
Picture Mode	✓	✓
Demo Surround	✓	✓
HDMI 1-4	✓	✓ (HDMI 1-3 only)
Action Menu	✓	—
Help	✓	✓

# RS232C コマンド

	Range/Switch Code				Support		
	Syntax	byte0:		byte1:	BZ model	EZ20L	
		Syntax	Code	Syntax&code			
Mode Control	Power				✓	✓	
	Standby Command				✓	✓	
Input Select	Toggle	0x00			✓	—	
	Video / SCART	0x02	0x01-0x03		✓	—	
	HDMI	0x04	#1-#5	0x01-0x05	✓	✓ #1-#3 only	
	PC	0x05	#1		✓	—	
	Shared Input	0x07	#1		✓	—	
	Composite	0x08	#1-#3		✓	✓ #1 only	
	Volume Control				✓	✓	
	Muting				✓	✓	
	Language				✓	✓	
	Off Timer(SLEEP)				✓	✓	
	Picture Off				✓	✓	
	Display				✓	✓	
Picture	Picture Mode				✓	✓	
Sound	Sound Mode				✓	—	
	Speaker Off				✓	—	
Screen	H Shift				✓	—	
	V Size				✓	—	
	V Shift				✓	—	
Wide	Toggle	0x00			✓	✓	
	Direct	0x01	Wide Zoom	0x00	✓	✓	
			Full	0x01	✓	✓	
			Zoom	0x02	✓	✓	
			Normal	0x03	✓	✓	
			PC_Normal	0x05	✓	—	
			PC_Full1	0x06	✓	—	
			PC_Full2	0x07	✓	—	
	Auto Wide				✓	✓	
	4:3 Mode				✓	✓	
Picture	Cine Motion (Cinema Drive)				✓	✓	
	Picture				✓	—	
	Brightness				✓	✓	
	Color (Colour)				✓	✓	
	Hue				✓	✓	
	Sharpness				✓	✓	
	SIRCS	Sircs emulation				✓	✓
	Signage Command	ID Command				✓	✓
product info1-info3				✓	✓		